

### Best Practices for Using Your RO System:

- **Flush the First Tank:** After your system is set up, it will take ~1 hour for the tank to fill completely. **Please empty the tank once and allow it to refill before using the water.** This ensures any air bubbles or carbon dust from the filters is cleared.
  - **Use Regularly:** Try to use water from the system regularly to prevent stagnation in the tank.
- 

### Understanding the Shut-Off Valves:

There are two **blue-handled quarter-turn shutoff valves** connected to your system:

- One on the **incoming water line** to the filters.
- One on the **line to the storage tank**.

→ **Inline (handle in same direction as tubing):** Water is flowing

→ **Across (handle perpendicular to tubing):** Water is shut off



These are important to know if you ever need to shut off the system for any reason.

---

### Annual Filter Replacement Instructions:

We recommend replacing your filters **once per year**. You can order replacements online, or send us a message we can do it for you.

To replace the filters yourself:

1. **Turn off both shutoff valves** (water line and tank).
2. **Open the RO faucet** to relieve pressure in the lines.
3. **Unscrew the used filters** and install the new ones.
4. **Turn both shutoff valves back on** and allow the tank to fill.
5. **Flush the first full tank** before use.